



## SEQUENCE

**i** Detection


**i** Recovery

**i** Resuming Normal Flight

DETECTION




Requires an immediate action



# RECOVERY

TOGA



Simultaneously:

Bank

Pitch

Speed Brakes



Wing level




Reduce



Check retracted

# RECOVERY

**TOGA**



Simultaneously:

**Bank**

**Pitch**

**Speed Brakes**



Wing level

Reduce


Check retracted

20 000 ft

A/C is **clean**

A/C is **not clean**

**TOGA**



Simultaneously:

**Bank**

**Pitch**

**Speed Brakes**

▶ Wing level

▶ Reduce

▶ Check retracted

Order FLAPS 1




No Config Change



# ORDER FLAPS 1

A/C is clean



# RECOVERY

A/C is **not** clean



Prepare **to counteract the pitch up effect** induced by thrust increment

# RESUMING NORMAL FLIGHT

When **above Vls** (Speed trend)



Apply normal go around procedure.

